

AT-HS6




audio-lechnic

Thank you for purchasing this Audio-Technica product. Before using the product, read through this user manual to ensure that you will use the product correctly. Please keep this manual for future reference.

## Safety precautions

- Keep the product out of the reach of small children to avoid accidental ingestion of screws, nuts and washers, or damage to product.
- Do not use the product for any purpose other than to mount a phono cartridge.
- Do not put the product in a location where it is exposed to direct sunlight, near heating devices, or in places with high temperatures, high humidity, or high concentrations of dust.
- Do not attempt to disassemble or modify the product.
- Do not subject the product to strong impact.

## Name of each part -





# Specifications

Material

: Aluminum

Weight (excluding cartridge installation screws)

Dimensions

Accessories

Approx. 9.3 g (0.33 oz) (including lead wires)
Approx. 8.4 g (0.30 oz) (excluding lead wires)


: 13.0 mm (0.51") × 21.4 mm (0.84") ector × 48.9 mm (1.93") (H × W ×D)

(excluding connector and protrusions)

Cartridge installation slotted screw (M2.6) (10 mm × 2 and 8 mm × 2),


Nut x 2, Plastic washer x 2

Specifications are subject to change without notice due to improvements.




# How to install

- Mount a cartridge onto the headshell using the cartridge installation slotted screw and plastic washer provided, and tighten lightly so that cartridge position can be adjusted.
  - When using a cartridge without threaded inserts, use screws and nuts to install the cartridge.
  - Take care that the screws are short enough so as not to touch and damage the record.
  - · Read the user manual of the cartridge.



- 2. Slide the lead tips over the cartridge connections.
  - Do not apply heat.
  - Use tweezers, small pliers, and non-magnetic screwdriver(s) to mount the headshell/cartridge.
  - •If a lead tip is loose, flatten it out slightly to attach it.
  - Layout of headshell leads




Loosen screws with a non-magnetic screwdriver and adjust for overhang. Tighten the screws firmly when position is fixed.

## Overhang adjustment



If you are unsure about the overhang adjustment, align the stylus tip with the stylus on the cartridge that originally came with the turntable (see figure below).



- 4. Attach the headshell to the tonearm.
- Refer to the turntable's user manual and adjust the tonearm balance, tracking force and anti-skate.

Other language versions of this manual are available for download at http://eu.audio-technica.com/

## Audio-Technica Corporation


2-46-1 Nishi-naruse, Machida, Tokyo 194-8666, Japan www.audio-technica.com ©2019 Audio-Technica Corporation

Global Support Contact: www.at-globalsupport.com

ver.1 2018.08.01 162501280-01-02 ver.2 2019.08.01



AT-HS6



# audio-technica

お買い上げありがとうございます。ご使用の前にこの取 扱説明書を必ずお読みのうえ、正しくご使用ください。 またいつでもすぐ読める場所に保管しておいてください。

# ■ 安全上の注意

本製品は安全性に充分な配慮をして設計していますが、 使いかたを誤ると事故が起こることがあります。事故を 未然に防ぐために下記の内容を必ずお守りください。

この表示は「取り扱いを誤った場合、使用者 が死亡または重傷を負う可能性があります」 を意味しています。

# 注意

この表示は「取り扱いを誤った場合、使用者 が傷害を負う、または物的損害が発生する 可能性があります」を意味しています。


# ⚠警告

幼児の手の届かないところに置かないでください。取り 付けビス、ナットやワッシャーなどの誤飲、事故の原因に なります。


# ⚠注意

- カートリッジを取り付ける用途以外には使用しないでく ださい。破損や事故の原因になります。
- 直射日光の当たる場所、暖房器具の近く、高温多湿やほ こりの多い場所に置かないでください。故障や不具合の 原因になります。
- 分解や改造はしないでください。故障の原因になります。
- 強い衝撃を与えないでください。故障の原因になります。

## ■ 各部の名称



# 天面



## ■ テクニカルデータ

: アルミニウム

: 約9.3g(リード線含む)、 (取り付けビス除く) 約8.4g(リード線除く)

部、突起部除く)


外形寸法(コネクター: 13.0×21.4×48.9mm(H×W×D)

付属品

取り付けビス(M2.6)(10mm×2, 8mm) ×2)、ナット×2、プラスチックワッシャー


×2

改良のため予告なく変更することがあります。




## ■ 接続のしかた

- 1. 本製品とカートリッジ(別売)を、付属の取り付けど ス. プラスチックワッシャーを使用して仮留めし、位 置を決めます。
  - インサートナット(埋め込み式)の付いていないカートリッジ を使用する場合は、取り付けビスとナットを使用してカートリッ ジを取り付けます。
  - 取り付けビスを上から通して固定する場合は、レコードに取 り付けビスが当たらないようにご注意ください。
  - で使用のカートリッジの取扱説明書も併せてご確認ください。




- 2. リード線の先端にあるリードチップをカートリッジ に差し込み接続します。
  - 絶対に熱などを加えないでください。
  - ヘッドシェルとカートリッジの取り付けには、市販のピンセッ ト、スモールベンチや非磁性マイナスドライバーなどを使用 して取り付けることをおすすめします。
  - リードチップが緩い場合は、少しつぶして接続してください。

### ●ヘッドシェルリード線の配列




 2カ所の取り付けビスを非磁性マイナスドライバー で緩めて、オーバーハングの調整をします。調整終 了後は取り付けビスを本締めしてください。

### オーバーハング調整



不明な場合は、ターンテーブルに最初から付い ているカートリッジの針先位置に合わせてくだ さい(下図)。



- 4. ターンテーブルのトーンアームに本製品を接続 します。
- 5. ターンテーブルの取扱説明書を参照し、水平バ ランス、針圧、アンチスケーティングの調整を行 います。

#### アフターサービスについて

本製品をご家庭用として、取扱説明や接続・注意書きに沿ったご 使用において万が一、製造上の原因による品質不良が発生した場 合は新品とお取り換えいたします。それ以外の責はご了承ください お取り換えの際は、お買い上げの確認のため領収書またはレシー トなどが必要になりますので大切に保管ください。

お問い合わせ先(電話受付/平日9:00~17:30) 製品の仕様・使いかたや修理・部品のご相談は、お買い上げのお 店または当社窓口およびホームページのサポートまでお願いします。

お客様相談窓口(製品の仕様・使いかた) **20**0120-773-417 (携帯電話・PHSなどのご利用は 03-6746-0211)

FAX:042-739-9120 Eメール: support@audio-technica.co.ip

サービスセンター(修理・部品) 000120-887-416 (携帯電話・PHSなどのご利用は 03-6746-0212)

FAX:042-739-9120 Eメール: servicecenter@audio-technica.co.jp

ホームページ(サポート)

www.audio-technica.co.jp/atj/support/

株式会社オーディオテクニカ

〒194-8666 東京都町田市西成瀬2-46-1 www.audio-technica.co.jp ©2019 Audio-Technica Corporation